



Notes:

- The wood cut out from the arm rest/ side part can be used as the braces underneath.
- Any desired design can be cut out of the back rest.
- The back rest should be placed 6" to 12" above the bench.
- The braces should be centered underneath of the seat.
- Any desired design can be cut out of the side pieces (curving design looks nice).

12' long piece of white pine
cut into four 3' pieces.

Mini Bench